

SLINGSHOT INSTALL INSTRUCTION

Thank you for purchasing the F4 Customs windshield for your Slingshot.

If you have an existing windshield remove the windshield so to prepare to install the F4 Customs shield. (If you do not have an existing windshield then the center post shown below and mounting hardware must be purchased from your dealer or F4 and installed prior to installing the F4 Customs Windshield.)

To install the F4 you will need your existing hardware and the additional 3-black plastic embossed washers and 1-rubber washers supplied by F4.

First insert the windshield into the slots on the inner dash of the Slingshot carefully resting the windshield on the center post. Then install the two outside bolts using the existing rubber washers under the shield and black plastic embossed washers on top of the shield. This cushions the windshield. Insert the existing bolts but do not tighten yet. Next place a rubber washer on the center post between the windshield and the center post (supplied by F4) Then place a black plastic embossed washer (both supplied by F4) and then put the existing bolt back in. All bolts can be then tightened. Do not over tighten these bolt as that can cause damage to the windshield. F4 Customs does not warranty windshields that have not been installed correctly or over tightened.

Once the shield is in place and the plastic film is removed, use either: household white vinegar or rubbing alcohol with paper towels to clean the windshield for the first time; this removes all residues left behind by the plastic that the windshield was packaged in.

Ride Safe!

F4 Customs
www.f4customs.com

