Step 1: Carefully loosen rubber boots between mirrors and plastic garnish.




<u>Step 2:</u>
Pull the plastic garnish away from bike using thumb tab to expose screws.





<u>Step 3:</u>
Raise windshield adjustment levers.



<u>Step 4:</u> Unscrew exposed Phillips head screws on both sides of chrome fairing.




<u>Step 5:</u>
Gently pull fairing away from bike and slide to the right and up to free fairing from bike.





<u>Step 6:</u>
Unscrew two outside screws first; then two inner then center to release the shield from the bike.





<u>Step 7</u>: Set fairing aside. Clean as desired.





Step 8:

Install new windshield in reverse order. When installing the windshield, please make sure to use the black screws and deep shoulder adjustment sleeves on the outside, and the gold screws and shallow adjustment sleeves on the inside three positions.







TO FINISH:

Make sure windshield is straight and tighten height levers.



Thank you for your F4 Customs windshield purchase. If you have any difficulties regarding the replacement process, please feel free to contact us.

You can also check out F4 Customs website at www.f4customs.com for a video tutorial on the installation of the GL 1500 windshields.

Questions? Comments?

sales@f4customs.com www.f4customs.com (330) 968-4644

^{***}F4 Customs is not responsible for any injury or harm to either the individual or product resulting from the installation process.